

2566 | Thermocouple Scanner Module, 12-channel



产品概述: 2566 | Thermocouple Scanner Module, 12-channel

This module has 12 channels and reads K, J, T, S, R, B, E, and N thermocouples. (Support for C and U type thermocouples is available. Download the application note [Using Fluke Calibration Readouts with Tungsten-Rhenium and other Thermocouples »](#)) Each channel can be set to read a different type of thermocouple. All temperature readings are performed in exactly the same manner as with the 2565 module.

The connectors on the scanner module are special dual connectors that accept both the common miniature and standard thermocouple connectors. If you want to use screw terminals, use the appropriately- sized connector with the hood removed.

型号



2566

热电偶模块（12个通道）



Fluke. 让您的工作畅通无阻。

福祿克测试仪器（上海）有限公司 电话：400-810-3435 ©2025 福祿克公司
06/2025
北京福祿克世祿仪器维修和服务有限公司 电
话：400-615-1563 未经许可，本文档禁止修改
福祿克测试仪器（上海）有限公司上海维修中心 电
话：021-54402301, 021-54401908分机269
福祿克测试仪器（上海）有限公司深圳第一特约维修点
电话：0755-86337229